


ZIM.613.101.06 Wiring for 912



- | | |
|----------------|--|
| 57a – Beige | To Turn Signal Switch – not used on replacement switch |
| 50 – Yellow | To Starter |
| 30 – Red | To Turn Signal Switch |
| 30 – Red | To Headlight Switch |
| 15 – Red | To Fuse Box #1 (Instruments) |
| 75 – White | To Radio |
| 75 – Red/White | To Connection Point at back of car. |